

Descrizione e funzionamento

Il presente dispositivo consente l'accensione dei trasformatori collegati, con gioco-luce flashing variabile da 0.5 a 2.5s.
 Il grado di protezione (IP 55) è garantito qualora i fori siano di misura adeguata.

Istruzioni di montaggio

Collegare gli alimentatori accertandosi che l'assorbimento non ecceda la portata del fusibile; collegare l'alimentazione ai morsetti di ingresso.
 Effettuare la regolazione di velocità agendo sul potenziometro presente.
 Nella centralina predisposta per crepuscolare, collegare il crepuscolare al relativo morsetto (non ha verso). Regolare la soglia di intervento del crepuscolare agendo sull'apposito trimmer.
 In caso di sostituzione del fusibile rimpiazzare con uno avente identiche caratteristiche.
 Togliere sempre la tensione di ingresso prima di effettuare qualsiasi operazione. Questo dispositivo non deve essere manomesso da personale non qualificato, in quanto può presentare rischio di choc elettrico.

Avvertenze

Il funzionamento dell'apparecchio è garantito solo nel rispetto dei dati di targa ed il telaio metallico dell'insegna è collegato all'impianto di terra e la sua resistenza sia conforme alle norme vigenti. Il mancato rispetto delle suddette prescrizioni può pregiudicare il funzionamento e causare guasti agli apparecchi oltre a far decadere la garanzia. Si raccomanda l'uso del dispositivo congiuntamente ai trasformatori Siet o Ricci.

Descriptions and working

The device permits the ignition of the connected transformers, with a blinking effect adjustable from 0.5 to 2.5s.
 The international protection (IP 55) is guaranteed only when the holes are of a adjusted measure and with the suitable fair-leads.


Assembly instructions


Connect the programmers to the output and make sure that the absorption does not exceed the fuse power; connect the supply to the input terminals.
 Make the speed regulation on the potentiometer.
 If available, connect the twilight switch to its terminal (see picture) and make its regulation on the trimmer.
 In case of a burned fuse, substitute it with another with the same characteristics.
 Always remove the supply voltage before making any operations.
 This device must not tampered by unskilled personnel, because it can cause an electric shock.

Attention

The device working is guaranteed only in the respect of label details and the metallic frame sign must be connected to the earth system and its resistance must be conforming to the regulations in force.
 Every failure in observing to the prescriptions, could cause irreparable damages to the machines or to the working and invalidates the warranty. We recommend the device use together with Siet or Ricci transformers.

Dimensioni – Size:	(mm) 160 x 120 x 80 (h)
Grado di protezione – Protection Degree:	IP55
Alimentazione – Current supply:	220-240V 50/60Hz
Morsetti – Terminals:	tripolari – tripolar
Carico massimo – Max load:	4A
Velocità – Speed:	0.5-2.5s regolabile – adjustable





Cablaggio relay in uscita per carichi maggiori di 4A -Optional output relay for loads greater than 4A